


UP-4000



UP-4000 SPARE PARTS LIST

NO.	PART'S NAME	1SET
1	YNUP4000 LEG4	1pc
2	YNUP4LEG5	1pc
3	YNUP4LEG6	1pc
4	YNUP4LEG7	1pc
5	Y4SOCKET	1pc
6	Y5SOCKET	1pc
7	Y6SOCKET	1pc
8	Y5BRAKE N	1pc
9	Y6 BRAKE N	1pc
10	Y4 LEVER	1pc
11	Y5 LEVER	1pc
12	Y6 LEVER	1pc
13	4 x 40 E PIN	1pc
14	4 x 36 E PIN	1pc
15	Y5 STOPPER A	1pc
16	Y5 STOPPER B	1pc
17	Y6 STOPPER A	1pc
18	Y6 STOPPER B	1pc
19	Y7 STOPPER A	1pc
20	Y7 STOPPER B	1pc
21	Y4 SLEEVE A	1pc
22	Y4 SLEEVE B	1pc
23	Y5 SLEEVE A	1pc
24	Y5 SLEEVE B	1pc
25	Y6 SLEEVE A	1pc
26	Y6 SLEEVE B	1pc
27	Y7 SPIKE RIB	1pc
28	Y7 HARD TIP SCREW	1pc
29	C7 HARD TIP RUBBER	1pc
30	UP4000 BAND	1pc
31	UP4000 PEDESTAL	1pc
32	UP-4000 ST CRIP	1pc
33	4 x 10.4 BLIND RIVET	1pc
34	P28 FOAM RBR TUBE	1pc
35	U1/4 x 12 PH	1pc